



WARNING!

This mirror is very heavy and may expose installers to injury if adequate precautions are not followed. Please allow a minimum of three experienced personal to install. Also review all procedures before proceeding.

- 1.) Remove all three wall angles by removing the swivel bolts and S hooks in the blue circles.
- 2.) Anchor these angles on a wall or existing structure. Installed angles should be spaced out exactly to allow perfect engagement with angles on the back of mirror.
- 3.) Lift the mirror and loosely insert swivel bolts at bottom of angles then attach chains to the top of angles.
- 4.) Adjust chain length on each angle to achieve maximum viewing for customers.
- 5.) Tighten all bolts and S hooks for permanent secure installation.